


# MODEL X1T8664

**SPOTNAILS®**  
 DIVISION OF PEACE INDUSTRIES, LTD.  
 1100 Hicks Rd  
 Rolling Meadows, IL 60008  
 Phone : 847-259-1620



05/21/2018

## SPOTNAILS MODEL X1T8664

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24300	Cap Screw-4	◆	35	P-64333 O-Ring
02	P-32211	Flat Washer-4	◆	36	P-64334 O-Ring
03	P-70058	Exhaust Deflector	◆	37	P-64335 O-Ring
04	P-60221	Cap		38	P-22145 Pilot Valve
◆	05	P-15187 Exhaust Seal	◆	39	P-64336 O-Ring
◆	06	P-64378 O-Ring		40	P-18227 Spring
	07	P-18327 Poppet Spring	◆	41	P-64383 Plunger O-Rings-2
◆	08	P-64601 Poppet O-Ring		42	AS-22037 Plunger Assembly
	09	P-63055 Poppet	◆	43	P-64328 O-Ring
◆	10	P-64379 Piston Stop o-Ring		44	P-18267 Spring
◆	11	P-64602 Cylinder Seal O-Ring		45	AS-21037 Restrictive Trigger Assembly (Red)
◆	12	P-62094 Gasket		46	P-32170 Washer
◆	13	P-64617 Piston O-Ring		47	P-24301 Screw
	14	P-06234 Driver Blade		48	P-13134 Bracket
	15	AS-06119 Piston & Driver Assembly		49	P-26126 Nut
	16	P-03125 Guide Spacer		50	P-24317 Screw
	17	P-05131 Cylinder		51	P-10259 Stationary Front Plate
◆	18	P-64603 Cylinder O-Ring		52	P-24380 Screw
◆	19	P-64604 O-Ring		53	P-52036 Safety Yoke Guide
	20	P-03126 Cylinder Guide		54	P-24306 Screw
◆	21	P-64605 O-Ring		55	P-10260 Removable Front Plate
	22	P-15278 Bumper		56	P-08461 Wear Plate
	23	P-15200 Return Seal		57	P-53169 Short Guide Assembly
◆	24	P-64240 O-Ring		58	P-24364 Screw
	25	P-01310 Body		59	P-12339 Guide Nail Cover
	26	P-64312 O-Ring		60	P-09165 Pusher
	27	P-60156 End Cap		61	P-18234 Negator Spring
	28	P-53165 Safety Guide		62	P-12370 Magazine(Left)
	29	P-18328 Spring		63	P-12369 Magazine(Right)
	30	AS-53090 Safety Assembly		64	P-03056 Spacer
	31	P-07327 Trigger Pin		65	P-24319 Screw
	32	P-07262 Pin		66	P-97454 Filter (Available)
◆	33	P-64332 Valve Housing O-Ring		67	AS-21008 Bump Fire Trigger (Black)
	34	P-22144 Trigger Valve Cap			

◆ Parts Included In AS-97403 O-Ring And Seal Kit